

Mobility Scooters

- ActiveCare Spitfire 1310 (Requires 2 Batteries)
- ActiveCare Spitfire EX 1420 (Requires 2 Batteries)
- ActiveCare Spitfire1410 (Requires 2 Batteries)
- BladeZ Electric Sport (Requires 2 Batteries)
- BladeZ Electric XTR Comp (Requires 2 Batteries)
- BladeZ Electric XTR Comp II (Requires 2 Batteries)
- BladeZ Electric XTR Lite (Requires 2 Batteries)
- BladeZ Electric XTR S 450 (Requires 2 Batteries)
- BladeZ Electric XTR Street II (Requires 2 Batteries)
- BladeZ Electric XTR Transport (Requires 2 Batteries)
- Bruno Rio Travel Scooter (Requires 2 Batteries)
- Currie XTR COMP2 (Requires 2 Batteries)
- Currie XTR SE 450 (Requires 2 Batteries)
- Currie XTR Street (Requires 2 Batteries)
- Currie XTR Transport (Requires 2 Batteries)
- Currie XTRS 450 (Requires 2 Batteries)
- Currie XTRS COMP (Requires 2 Batteries)
- DDC Shoprider Scootie (Requires 2 Batteries)
- DDC Shoprider Traveler (Requires 2 Batteries)
- Drive Medical Falcon 3 (Requires 2 Batteries)
- Drive Medical Falcon 4 (Requires 2 Batteries)
- Drive Medical Geo_Portable (Requires 2 Batteries)
- Drive Medical Mini Phantom (Requires 2 Batteries)
- Drive Medical Phantom (Requires 2 Batteries)
- Drive Medical Phoenix 3 (Requires 2 Batteries)
- Drive Medical Phoenix 4 (Requires 2 Batteries)
- Frank Mobility E-Fix (Requires 2 Batteries)
- Golden Technologies Buzzaround Models (Requires 2 Batteries)
- Hoveround Activa Mini (Requires 2 Batteries)
- Invacare Zoom3 (Requires 2 Batteries)
- Pride Mobility Go Go (Requires 2 Batteries)
- Pride Mobility Sonic (Requires 2 Batteries)
- Quickie Melody (Requires 2 Batteries)
- Quickie P11 (Requires 2 Batteries)
- Rascal MicroBalance 170 (Requires 2 Batteries)
- Rascal We Go 250 (Requires 2 Batteries)

- Rascal We Go 255 (Requires 2 Batteries)
- Shoprider Dasher 3 (Requires 2 Batteries)
- Shoprider Dasher 4 (Requires 2 Batteries)
- Shoprider EZ Chopper (Requires 2 Batteries)
- Shoprider Jimmie (Requires 2 Batteries)
- Shoprider Scootie (Requires 2 Batteries)
- Shoprider Scootie Jr (Requires 2 Batteries)
- Shoprider Start (Requires 2 Batteries)
- Shoprider Sunrunner S (Requires 2 Batteries)
- Sunrise Medical Guardian Trek 3 (Requires 2 Batteries)
- Sunrise Medical Guardian Trek 4 (Requires 2 Batteries)
- Theradyne EV1864 (Requires 2 Batteries)
- Zip'r Zip'r3 Traveler (Requires 2 Batteries)
- Zip'r Zip'r3 Xtra Hybrid Traveler (Requires 2 Batteries)
- Zip'r Zip'r4 Traveler (Requires 2 Batteries)
- Zip'r Zip'r4 Xtra Hybrid Traveler (Requires 2 Batteries)

UPS Batteries

- RBC Battery Cartridges RBC3
- RBC Battery Cartridges RBC4
- APC BACK-UPS 1000 (Requires 2 Batteries)
- APC BACK-UPS 650
- APC BACK-UPS 650 Pro
- APC BACK-UPS 650MC
- APC BACK-UPS BK1000 (Requires 2 Batteries)
- APC BACK-UPS BK650
- APC BACK-UPS BK650M
- APC BACK-UPS BK650MC
- APC BACK-UPS BK650MUC
- APC BACK-UPS BK650X06
- APC BACK-UPS ES BE750-CN
- APC BACK-UPS ES BE750BB
- APC BACK-UPS LS BP650S
- APC BACK-UPS PCNET (Requires 2 Batteries)
- APC BACK-UPS PRO BP1000 (Requires 2 Batteries)
- APC BACK-UPS PRO BP650
- APC BACK-UPS PRO BP650C

- APC BACK-UPS PRO BP650IPNP
- APC BACK-UPS PRO BP650PNP
- APC BACK-UPS PRO BP650S
- APC BACK-UPS PRO BP650SC
- APC BACK-UPS PRO BP650SUS
- APC BACK-UPS PRO BP650SX107
- APC BACK-UPS VS SUVS1000 (Requires 2 Batteries)
- APC BACK-UPS VS SUVS650
- APC RBC3
- APC RBC4
- APC RBC6
- APC SMART-UPS 1000 (Requires 2 Batteries)
- APC SMART-UPS 1000NET (Requires 2 Batteries)
- APC SMART-UPS 1000RM (Requires 2 Batteries)
- APC SMART-UPS RM SU1000RM (Requires 2 Batteries)
- APC SMART-UPS RM SU1000RMNET (Requires 2 Batteries)
- APC SMART-UPS RM SU1500RMX155 (Requires 2 Batteries)
- APC SMART-UPS RM SU2000R3X155 (Requires 4 Batteries)
- APC SMART-UPS SC620
- APC SMART-UPS SU1000 (Requires 2 Batteries)
- APC SMART-UPS SU1000 RACK (Requires 2 Batteries)
- APC SMART-UPS SU1000BX120 (Requires 2 Batteries)
- APC SMART-UPS SU1000NET (Requires 2 Batteries)
- APC SMART-UPS SU1000RM (Requires 2 Batteries)
- APC SMART-UPS SU1000RMNET (Requires 2 Batteries)
- APC SMART-UPS SU1000X127 (Requires 2 Batteries)
- APC SMART-UPS SU1000X93 (Requires 2 Batteries)
- APC SMART-UPS SU520NET
- APC SMART-UPS SU620NET
- APC SMART-UPS SU650
- APC SMART-UPS SU650VS
- APC SMART-UPS SU700X167 (Requires 2 Batteries)
- APC SMART-UPS SUA1000 (Requires 2 Batteries)
- APC SMART-UPS SUA1000US (Requires 2 Batteries)
- APC SMART-UPS SUVS1000 (Requires 2 Batteries)
- APC SMART-UPS SUVS650
- Belkin BERBC55 (Requires 2 Batteries)

- Belkin F6C1000-EUR (Requires 2 Batteries)
- Belkin F6C320 (Requires 4 Batteries)
- Belkin Omnigaurd 3200 (Requires 4 Batteries)
- Belkin Pro F6C100 (Requires 2 Batteries)
- Belkin Pro NETUPS F6C100 (Requires 2 Batteries)
- Belkin Regulator Pro Net 1000 (Requires 2 Batteries)
- Compaq T700
- Conext 900AVR
- Cyber Power CS24U12V-12
- Data Shield 400
- Data Shield AT5000 (Requires 2 Batteries)
- Data Shield TURBO 2-450
- Deltec PRB500
- Deltec PRM700
- Elgar SPS1000 (Requires 4 Batteries)
- Emerson 800 (Requires 2 Batteries)
- Emerson AU-750-60 (Requires 3 Batteries)
- MGE ESV22 (Requires 4 Batteries)

Electric Scooters

- BladeZ XTR Comp 450 (Requires 2 Batteries)
- BladeZ XTR Street 2 (Requires 2 Batteries)
- BladeZ XTR Street 450 (Requires 2 Batteries)
- BladeZ XTR-HD 550 (Requires 2 Batteries)
- BladeZ XTR-S 450 (Requires 2 Batteries)
- BladeZ XTR-S Transport 450 (Requires 2 Batteries)
- BladeZ XTR-SE 450 (Requires 2 Batteries)
- Boreem Jia 601-S 24V (Requires 2 Batteries)
- Boreem Jia 601-S 36V (Requires 3 Batteries)
- Boreem Jia 602-D 24V (Requires 2 Batteries)
- Boreem Jia 602-D 36V (Requires 3 Batteries)
- Boreem S350 24V (Requires 2 Batteries)
- Boreem S350 36V (Requires 3 Batteries)
- Boreem Tankman
- E-Scooter 24 Volt 250 Watt (Requires 2 Batteries)
- E-Scooter 36 Volt 350 Watt (Requires 3 Batteries)
- Electra Scoot-N-Go (Requires 2 Batteries)

- Electra Voy (Requires 3 Batteries)
- eZip eZip 750 (Requires 2 Batteries)
- eZip eZip 900 (Requires 2 Batteries)
- Freedom 644 Electric Scooter (Requires 2 Batteries)
- iZip AL-1020 (Requires 2 Batteries)
- iZip HG1000 (Requires 3 Batteries)
- iZip MTN24V450 (Requires 2 Batteries)
- iZip MTNAL24V450 (Requires 2 Batteries)
- iZip TriCruiser (Requires 3 Batteries)
- iZip Via Mezza (Requires 2 Batteries)
- Mongoose AL 1020 (Requires 2 Batteries)
- Mongoose CB24V450 (Requires 2 Batteries)
- Mongoose CBAL24V450 (Requires 2 Batteries)
- Mongoose CR24V450 (Requires 2 Batteries)
- Mongoose CR36V450 (Requires 3 Batteries)
- Mongoose CX24V200 (Requires 2 Batteries)
- Mongoose CX24V450 (Requires 2 Batteries)
- Mongoose Dirt Grinder (Requires 2 Batteries)
- Mongoose HG1000 (Requires 3 Batteries)
- Mongoose J3 (Requires 3 Batteries)
- Mongoose MTN24V450 (Requires 2 Batteries)
- Mongoose MTNAL24V450 (Requires 2 Batteries)
- Rad2Go Great White E36 (Requires 3 Batteries)
- Rad2Go Leopard Shark E5 (Requires 2 Batteries)
- Rad2Go Reflexx (Requires 2 Batteries)
- Rad2Go Rocket Racer (Requires 3 Batteries)
- Rad2Go ZZ Cruiser (Requires 2 Batteries)
- Rad2Go ZZ Rider (Requires 2 Batteries)
- Razor E500s (Requires 2 Batteries)
- Razor MX500 Dirt Rocket (Requires 3 Batteries)
- Razor MX650 Dirt Rocket (Requires 3 Batteries)
- SEA-DOO SeaScooter GTI
- SEA-DOO SeaScooter VS Supercharged
- Sola 350 Cruiser (Requires 3 Batteries)
- Sola X-11 (Requires 2 Batteries)
- SunL Big Bug (Requires 2 Batteries)
- SunL E-21 (Requires 2 Batteries)

- SunL ES-40 (Requires 3 Batteries)
- SunL SLE-380 (Requires 2 Batteries)
- SunL SLE-500 (Requires 2 Batteries)
- SunL SLE-750 (Requires 3 Batteries)
- SunL Tiger (Requires 2 Batteries)
- X-Treme X-11 (Requires 2 Batteries)
- X-Treme X-150
- X-Treme X-151
- X-Treme X-360 (Requires 3 Batteries)
- X-Treme X-50-300 (Requires 2 Batteries)
- X-Treme X-560 (Requires 3 Batteries)
- X-Treme X-600 (Requires 3 Batteries)
- X-Treme XA-750 v1 (Requires 3 Batteries)
- X-Treme XB-500 (Requires 4 Batteries)
- X-Treme XB-502 (Requires 4 Batteries)
- X-Treme XB-508 (Requires 4 Batteries)
- X-Treme XM-500 (Requires 3 Batteries)
- X-Treme XP-700 (Requires 3 Batteries)
- Xcooter Xcruiser XC266GTB (Requires 2 Batteries)
- Xcooter Zipper XC533GTG (Requires 2 Batteries)
- Currie e-Ride 20
- Currie e-Ride 26
- Currie e-Ride 16

Alarm Batteries

- ADI 25360
- ADI PWPS12120
- Altronix AL1002UL2ADA
- Altronix AL1002UL2ADAJ
- Altronix AL1002ULADA
- Altronix AL1002ULADAJ
- Altronix AL1012ULACM
- Altronix AL1012ULACMCB
- Altronix AL1012ULACMCBJ
- Altronix AL1012ULACMJ

- Altronix AL1012ULM
- Altronix AL1012ULX
- Altronix AL1012ULXPD16
- Altronix AL1012ULXPD16CB
- Altronix AL1012ULXPD4
- Altronix AL1012ULXPD4CB
- Altronix AL1012ULXPD8
- Altronix AL1012ULXPD8CB
- Altronix AL1024ULACM
- Altronix AL1024ULACMCB
- Altronix AL1024ULACMCBJ
- Altronix AL1024ULACMJ
- Altronix AL1024ULM
- Altronix AL1024ULX
- Altronix AL1024ULXPD16
- Altronix AL1024ULXPD16CB
- Altronix AL1024ULXPD4
- Altronix AL1024ULXPD4CB
- Altronix AL1024ULXPD8
- Altronix AL1024ULXPD8CB
- Altronix AL1024ULXR
- Altronix AL1042UL2ADA
- Altronix AL1042ULADA
- Altronix AL175ULX2
- Altronix AL300ULXD
- Altronix AL300ULXPD16
- Altronix AL300ULXPD16CB
- Altronix AL400UL3X
- Altronix AL400ULACM
- Altronix AL400ULACMCB
- Altronix AL400ULACMCBJ
- Altronix AL400ULACMJ
- Altronix AL400ULADA
- Altronix AL400ULXPD16
- Altronix AL400ULXPD16CB
- Altronix AL600UL3X
- Altronix AL600ULACM
- Altronix AL600ULACMCB